

Owner's Guide

Gas Range

with

Self-Cleaning Oven

TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	1-4	Automatic oven cooking	
CLOCK, TIMER, OVEN CONTROL	5-6	Broiling and chart, select models	
SURFACE COOKING	7-10	SELF-CLEAN OVEN	
Pilotless ignition system	7	CARE AND CLEANING CHART	
Lighting surface burners	7	MAINTENANCE	
Selecting flame size	8	Cooktop	
About the surface flame	8	Burner grates	
Adjusting the flame	8	Oven light	
Conventional surface burners, select models	9	Oven door	
Sealed surface burners, select models	9	Door lock lever	
Cookware	10	Oven bottom	
Canning	10	Oven racks	
OVEN USE	11-18	Storage drawer	
Pilotless ignition system	11	Leveling legs	
Oven burner	11	How to remove range for cleaning and	
Oven vent	11	SERVICE	
General information	11	Electrical connection	
How to set oven to bake or roast	12	Proportional valve adjustment	
General baking tips	13	Adjusting oven temperature	
Preheating	13	Explanation of fault codes	
Use of aluminum foil	13	How to obtain service	
Common baking problems	14	Troubleshooting chart	
Roasting and chart	15		

INSTALLER Please leave this manual with this appliance.

CONSUMER To save you time, energy and money, read and keep this manual for future reference.

The model and serial numbers are found on the rating plate located on the sides of the lower range front frame.

Model Number: _____

Serial Number: _____

Date of Purchase: _____

Please keep your sales receipt and/or your cancelled check with this booklet. Purchase should warranty service be needed. Store these documents.

FOR CUSTOMER ASSISTANCE CALL 1-800-688-1120

Read all instructions before using this appliance.

Thank You . . . for purchasing our cooking appliance. To help you obtain the maximum in cooking satisfaction, we offer these suggestions:


- ☞ Read this manual before using the appliance.
- ☞ Review all safety and caution instructions.
- ☞ Review the Troubleshooting Chart on pages 30 and 31 if service becomes necessary.
- ☞ Include the model and serial numbers of your appliance when requesting service.
 - Proof of purchase such as sales receipt will be needed for warranty service.
- ☞ You can contact us at:

Customer Assistance
% Maytag Customer Service
P. O. Box 2370
Cleveland, TN 37320-2370
1-800-688-1120

In our continuing effort to improve the quality and performance of our cooking appliances, it may be necessary to make changes to the appliance without revising this manual.

WARNING: If the information manual is not followed exactly, explosion may result causing damage, personal injury or death.

- Do not store or use gasoline flammable vapors and liquid in vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
 - Do not try to light any appliances.
 - Do not touch any electrical switches. Do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

	! WARNING • ALL RANGES CAN TIP AND CAUSE INJURIES TO PERSONS. • INSTALL ANTI-TIP DEVICES PACKED WITH RANGE. • FOLLOW ALL INSTALLATION INSTRUCTIONS.
---	---

WARNING: To reduce the risk of tipping of this appliance from abnormal usage or by excessive force on the oven door, the appliance must be secured with a properly installed anti-tip device.

If the range is moved from the wall, be sure the anti-tip device is engaged when the range is replaced. Check underneath range to verify that one of the rear legs is properly engaged in the bracket slot.

The anti-tip device secures the rear leveling leg to the floor when properly engaged. Also, be sure the anti-tip device is properly re-installed.

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

The following instructions are based on safety considerations and must be strictly followed to eliminate the potential risks of fire, electric shock, or personal injury.

Have your appliance installed and properly grounded by a qualified installer according to the installation instructions. Have the installer show you the location of the gas shut off valve and how to shut it off in an emergency.

Always disconnect power to appliance before servicing.

To ensure proper operation and avoid possible injury or damage to unit do not attempt to adjust, repair, service, or replace any part of your appliance unless it is specifically recommended in this book. All other servicing should be referred to a qualified installer or servicer.

TO PREVENT FIRE OR SMOKE DAMAGE

Be sure all packing materials are removed from the appliance before operating it.

Keep area around appliance clear and free from combustible materials, gasoline, and other flammable vapors and materials.

If appliance is installed near a window, proper precautions should be taken to prevent curtains from blowing over burners.

NEVER leave any items on the cooktop. The hot air from the vent may ignite flammable items and may increase pressure in closed containers which may cause them to burst.

Many plastics are vulnerable to heat. Keep plastics away from parts of the appliance that may become warm or hot. Do not leave plastic items on the cooktop as they may melt or soften if left too close to the vent or a lighted surface burner.

Many aerosol-type spray cans are **EXPLOSIVE** when exposed to heat and may be highly flammable. Avoid their use or storage near an appliance.

To eliminate the hazard of reaching over hot surface burners, cabinet storage should not be provided directly above a unit. If such storage is provided, it should be limited to items which are used infrequently and which are safely stored in an area subjected to heat from an appliance. Temperatures may be unsafe for some items, such as volatile liquids, cleaners or aerosol sprays.

IN CASE OF FIRE

Turn off appliance and ventilating hood to avoid the flame. Extinguish flame then turn on hood to remove smoke and odor.

Use dry chemical or foam-type extinguisher or soda to smother fire or flame. Never use water on grease fire.

If fire is in the oven or broiler pan, smother fire by closing oven door.

If fire is in a pan on the surface burner, cover pan with lid and attempt to pick up or move a flaming pan.

CHILD SAFETY

NEVER leave children alone or unsupervised near appliance when it is in use or is still hot. **NEVER** allow children to sit or stand on any part of the appliance.

Children must be taught that the appliance and utensils in it can be hot. Let hot utensils cool in a safe place, out of reach of small children. Children should be taught that an appliance is not a toy. Children should not be allowed to play with controls or other parts of the unit.

CAUTION: NEVER store items of interest to children in cabinets above an appliance or on the backguard of a range. Children climbing on the appliance or on the appliance door to reach items could be seriously injured.

ABOUT YOUR APPLIANCE


NEVER use appliance as a space heater to heat or warm a room to prevent potential hazard to the user and damage to the appliance. Also, do not use the cooktop or oven as a storage area for food or cooking utensils.

Do not obstruct the flow of combustion air by blocking the oven vent or air intakes. Restricted air flow to the burner prevents proper performance and increases carbon monoxide emission to



Avoid touching oven vent area while oven is on and for several minutes after oven is turned off. Some parts of the vent and surrounding area become hot enough to cause burns. After oven is turned off, do not touch the oven vent or surrounding areas until they have had sufficient time to cool.

WARNING: NEVER use appliance door or drawer, if equipped, as a step stool or seat as this may result in possible tipping of the appliance, damage to the appliance, and serious injury.




Do not touch a hot oven light bulb with a damp cloth as the bulb could break. Should the bulb break, disconnect power to the appliance before removing bulb to avoid electrical shock.

COOKING SAFETY

Always place a pan on a surface burner before turning it on. Be sure you know which knob controls which surface burner. Make sure the correct burner is turned on and that the burner has ignited. When cooking is completed, turn burner off before removing pan to prevent exposure to burner flame.

Always adjust surface burner flame so that it does not extend beyond the bottom edge of the pan. An excessive flame is hazardous, wastes energy and may damage the appliance, pan or cabinets above the appliance.

NEVER leave a surface cooking operation unattended especially when using a high heat setting or when deep fat frying. Boilovers cause smoking and greasy spillovers may ignite. Clean up greasy spills as soon as possible. Do not use high heat for extended cooking operations.




NEVER heat an unopened container on the surface burner or in the oven. Pressure build-up may cause container to burst resulting in serious personal injury and damage to the appliance.

Use dry, sturdy pot holders. Damp pot holders can cause burns from steam. Dish towels or other substitutes never be used as pot holders because they can slip across hot surface burners and ignite or get caught in appliance parts.

Always let quantities of hot fat used for deep frying cool before attempting to move or handle.

Do not let cooking grease or other flammable liquids accumulate in or near the appliance, hood or vent. Clean hood frequently to prevent grease from accumulating on hood or filter. When flaming food in the hood turn the fan off as the fan may spread flames.

NEVER wear garments made of flammable material or loose fitting or long hanging-sleeved apparel while cooking. Clothing may ignite or catch utensil handles.



Always place oven racks in the desired position while oven is cool. Slide oven rack out to add or remove food using dry sturdy pot holders. Always avoid reaching into the oven to add or remove food. If a rack must be removed while hot, use a dry pot holder. Always turn the oven off at the end of cooking.

Use care when opening the oven door. Let hot steam escape before removing or replacing food.

PREPARED FOOD WARNING: Follow food manufacturer's instructions. If a plastic frozen food container and/or its cover distorts, warps, or is damaged during cooking, immediately discard the food and its container. The food could be contaminated.


IMPORTANT SAFETY INSTRUCTIONS

UTENSIL SAFETY

Use pans with flat bottoms and handles that are easily grasped and stay cool. Avoid using unstable, warped, easily tipped or loose handled pans. Also avoid using pans especially small pans, with heavy handles as they could be unstable and easily tip. Pans that are heavy to move when filled with food may also be hazardous.

Be sure utensil is large enough to properly contain food and avoid boilovers. Pan size is particularly important in deep fat frying. Be sure pan will accommodate the volume of food that is to be added as well as the bubble action of fat.

To minimize burns, ignition of flammable materials and spillage due to unintentional contact with the utensil, do not extend handles over adjacent surface burners. Always turn pan handles toward the side or back of the appliance, not out into the room where they are easily hit or reached by small children.



Never let a pan boil dry as this could damage the utensil and the appliance.

Follow the manufacturer's directions when using oven cooking bags.

Only certain types of glass, glass/ceramic, ceramic, or glazed utensils are suitable for cooktop or oven usage without breaking due to the sudden change in temperature.

This appliance has been tested for safe performance using conventional cookware. Do not use any devices or accessories that are not specifically recommended in this manual. Do not use eyelid covers for the surface units, stove top grills, or add-on oven convection systems. The use of devices or accessories that are not expressly recommended in this manual can create serious safety hazards, result in performance problems, and reduce the life of the components of the appliance.

CLEANING SAFETY

Turn off all controls and wait for appliance to cool before touching or cleaning them. Do not touch grates or surrounding areas until they have time to cool.

Clean appliance with caution. Use care to avoid burns if a wet sponge or cloth is used to wipe hot surface. Some cleaners can produce noxious fumes if applied to a hot surface.

SELF-CLEAN OVEN

Clean only parts listed in this manual. Do not clean the door gasket. The door gasket is essential for a good seal. Do not rub, damage, or move the gasket. Do not use oven cleaners of any kind in or around the part of the self-clean oven.

Before self-cleaning the oven, remove broiler racks, and other utensils, and wipe off excess grease and spillovers to prevent excessive smoke or flames.

CAUTION: Do not leave food or cooking utensils in the oven during the self-clean cycle.

It is normal for the cooktop of the range to become hot during a self-clean cycle. Therefore, touching the cooktop during a clean cycle should be avoided.


IMPORTANT SAFETY NOTICE AND WARNING

The California Safe Drinking Water and Toxic Substances Act of 1986 (Proposition 65) requires the State of California to publish a list of substances known to cause cancer or reproductive harm, and requires businesses to warn customers about exposures to such substances.

Users of this appliance are hereby warned that the burning of gas can result in low-level exposures to the listed substances, including benzene, formaldehyde, and soot, due primarily to the incomplete combustion of natural gas or liquid petroleum (LP) fuels. The use of properly adjusted burners will minimize incomplete combustion. Exposure to these substances can also be minimized by properly venting the burners to the outdoors.

SAVE THESE INSTRUCTIONS

Press this pad to cancel all operations except the TIMER. The time of day will reappear in the display.



Select models will not feature broiling.

ABOUT THE FUNCTION PADS

- Function pads are the BAKE, BROIL, SELF-CLEAN, TIMER, CLOCK, COOK TIME, STOP TIME, and CANCEL pads. A beep will sound when these pads are pressed.
- No beep will sound when the ▲ or ▼ pad is pressed.
- All function pads except the CANCEL pad feature an indicator light.

When the BAKE or BROIL pad is pressed, the indicator light will turn on to let you know that the oven is set for this operation.




Indicator lights on SELF-CLEAN, TIMER, CLOCK, COOK TIME and STOP TIME pads will **flash** when the pad is pressed. These indicator lights will stop flashing but will remain lit once the function starts.

- If an indicator light on a function pad is lit and you set a second operation:
 - Either the control will not accept the operation or
 - The indicator light on the first pad will "dim" slightly and the indicator light on the pad you just pressed will be "full on." This lets you know that you have set the control for two operations.

For example: If you set the oven to bake at 350°F and then set a timing operation, the indicator light on the BAKE pad will "dim" and the indicator light on the TIMER pad will be "full on."

The display will show the operation for the pad with the "full on" indicator light. Press the function pad with the "dim" indicator light to recall that operation.



HOW TO SET CLOCK

- Press CLOCK pad.
- Press or press and hold ▲ or ▼ pad until correct time of day appears in display.



Display will flash when power is supplied to unit.

Press CLOCK pad to recall time of day when a function is displayed.

Clock time cannot be changed if oven is set for bake or delayed clean operation. Cancel the operation before setting the clock.

If timer is in use, press CLOCK pad **once** to recall time of day or **twice** to reset the time of day.

CLOCK DISPLAY DISABLE FEATURE

If you prefer that the time of day is not displayed:

- Press and hold **both** CLOCK and CANCEL pads for **3 seconds**.



When clock display is disabled, press CLOCK pad to recall time of day. Display will then blank.


If a power failure occurs when the clock has been disabled, the display remains blank and will not show time when power is restored.

Repeat step 1 to reactivate clock feature.

CLOCK, TIMER, OVEN CONTROL

HOW TO SET TIMER

1. Press TIMER pad.
2. Press or press and hold ▲ or ▼ pad until correct time appears in display.



The timer feature does not operate the oven.

The timer can be set from 1 minute [0:01] up to 9 hours and 50 minutes [9:50].


The timer will start automatically. The TIMER indicator on the TIMER pad will light whenever the timer is in use. One long beep and "End" will be briefly displayed to signal the end of the timer operation.

To cancel timer: Press and hold TIMER pad for 3 seconds. Time of day will reappear in the display.

12 HOUR ENERGY SAVER FEATURE

The 12 Hour Energy Saver feature automatically turns off the oven if it was accidentally left on for 12 hours. To deactivate this feature so the oven will NOT turn off automatically at the end of 12 hours:

1. Press and hold CLOCK pad for 3 seconds.
2. Press ▲ or ▼ pad until 8:88 appears in the display. Current time of day will reappear in the display after 4 seconds.



Repeat steps 1 and 2 to reactivate the 12 Hour Energy Saver feature. 12:00 will appear in display to indicate the Energy Saver feature is restored.

CONTROL LOCK-OUT FEATURE

The Control Lock-Out feature prevents the being turned on.

To activate:

1. Press and hold **both** STOP TIME and CANCEL pads for 3 seconds.
2. "OFF" will appear in display when this feature is activated. Only the timer functions will operate when Control Lock-Out feature is activated.

Repeat step 1 to deactivate.



"END OF TIMED COOK" BEEPS

You have a choice of three "end of cooking" beeps for the Automatic Oven Timer feature.

- **Option 1:** Four beeps then one beep every 30 seconds for the next 5 minutes or until CANCEL is pressed. (Default option.)
- **Option 2:** Four beeps. There are no other beeps.
- **Option 3:** Four beeps then one beep every 30 seconds for the next 12 hours or until CANCEL is pressed.

How to select the desired option:

1. Press and hold **both** COOK TIME and CLOCK pads for 3 seconds.
 - A single beep will sound.
 - Display will show current option.
2. Press ▲ or ▼ pad to select the option number you wish. The current time of day will reappear in the display after 4 seconds.




PILOTLESS IGNITION SYSTEM

Your range is equipped with pilotless ignition. Be sure all surface controls are set in the OFF position prior to supplying gas to the appliance.

IMPORTANT: When the appliance is first installed, the surface burners may be difficult to light due to air in the gas line. This may also occur if the appliance has been disconnected from the main gas supply or if it has not been used for several days or weeks.

To remove the air in the gas line, hold a lighted match next to the burner head and turn the knob on. When the burner lights, either adjust the knob to the desired flame size or turn the burner off.

Pilotless ignition uses a spark from the ignitor to light the burner. There are two ignitors for conventional surface burners. Each sealed burner has its own ignitor. Once the burner lights, turn the knob to the desired setting. The clicking sound will not stop until the knob is turned from the LITE position.



NOTE: The surface burner will not light if the ignitor is damaged, broken, soiled or wet. Also, the burner will not light if the small port beneath the ignitor is blocked. See page 23 for cleaning instructions.

LIGHTING SURFACE BURNERS


To prevent damage to the cooktop or pan, never place a surface burner without a pan in place, never allow a burner to boil dry and never operate a surface burner for extended periods of time.

To light surface burner:

1. Place a pan on the burner grate.

NOTE: The burner flame may lift off the burner and a "roaring" sound may be heard if a pan is placed on the grate before lighting the burner.

2. Push in and turn knob to the LITE position.



A clicking sound will be heard and the burner will light. When one burner is turned on, all ignitors will stop clicking.

3. After the burner lights, turn the knob to the desired flame size. The ignitors will continue to spark until the knob is turned from the LITE position.

CAUTION: If the flame should go out during operation, turn the burner off. If gas has accumulated and a strong gas odor is detected, wait 5 minutes for the gas odor to disappear before relighting burner.

To light surface burner during a power failure:


1. Be sure all controls are in the OFF position.
2. Hold a lighted match to the desired surface burner head.
3. Push in and turn knob to the LITE position. The burner will then light.
4. Adjust the flame to the desired flame size.

CAUTION: When lighting the surface burner, all of the controls are in the OFF position. Strike match first and hold it in position before turning knob to the LITE position.

SURFACE COOKING


SELECTING FLAME SIZE

Use a HIGH flame setting to quickly bring liquids to a boil or to begin a cooking operation. Then reduce to a lower setting to continue cooking. **Never leave food unattended when using a HIGH flame setting.**




An intermediate flame size is used to continue a cooking operation. **Food will not cook any faster when a higher flame setting is used than needed to maintain a gentle boil.** Remember, water boils at the same temperature whether boiling gently or vigorously.

Use LO to simmer or keep foods at serving temperatures.



Some cooking may take place on the LO setting if the cooking utensil is covered. If food does boil on the LO setting, it is possible to reduce the heat by rotating the knob toward the OFF position.



Be sure to adjust the knob so there is an adequate supply of gas to maintain a stable flame on the burner. Check to be sure burner is lit and the flame is stable.

ABOUT THE SURFACE BURNER

A properly adjusted burner with clean ports lights in a few seconds.

On natural gas, the flame will be blue with a core; there should be no trace of yellow in


A yellow flame indicates an improper mixture. This wastes fuel, so have a serviceman adjust if a yellow flame occurs.

On LP gas, some yellow tipping is acceptable and normal and adjustment is not necessary.

You may hear a "popping" sound on some burners when the surface burner is turned off. This is the normal operating sound of the burner.

ADJUSTING THE FLAME

Adjust the flame size so it does not extend beyond the edge of the cooking utensil. This is for personal safety and to prevent possible damage to the appliance, pan, or cabinets above the appliance. This also improves cooking efficiency.




NOTE: If a knob is turned very quickly from the LO setting, the flame may go out, particularly if the burner is cold. If this occurs, turn the knob to the OFF position. Wait several seconds, then light the burner.

CONVENTIONAL SURFACE BURNERS

Under no circumstances are the surface burner assemblies to be taken apart for cleaning. The surface burner assembly can be removed to clean the burner box area.

The two surface burner assemblies are secured in place during transportation with screws. Once the range is installed, these screws may be removed to allow quick and easy removal of the burner assemblies.



To remove: Allow the burner assembly to cool. Lift up cooktop. Grasp the burner assembly and rotate it slightly toward the left to release the two tabs on the assembly. Then lift the assembly and pull toward the back of the cooktop until the air shutter ends on the assembly release from the valves.

To replace: Insert the air shutter ends on the burner assembly over the valves and lower the assembly into place. Be sure to secure the two tabs on the burner assembly into the two slots on the burner support bracket which is mounted to the burner box bottom. (**NOTE:** If the tabs are not properly inserted into the slots, the assembly may rock and the burners may not light properly.)


SEALED SURFACE BURNERS

The porcelain on the burner is durable but over time with use may gradually lose its shine.

The sealed surface burners are secured to the cooktop and are NOT designed to be removed by the user.

Select models feature one or two special **SURFACE SPEED** sealed burners located at the right-front and left-rear. Use these burners to quickly bring water to a boil and when using larger pans. See information plate, located on the lower range front frame, broiler door or lower panel, to determine if your model features these burners.

Clean burner cap after each use especially if grease occurs. A soiled burner may result in improper flame and an uneven flame. When cleaning the sealed surface burner, use care to prevent damage to the ignitor. A cleaning cloth should catch the ignitor, it could be damaged or broken.



The surface burner will not light if the ignitor is broken, soiled or wet. The burner will also not light if the ports, especially the small port located directly below the ignitor, are blocked.

SURFACE COOKING

COOKWARE CONSIDERATIONS

Cookware which extends more than two inches beyond the grate, rests on two grates, or touches the cooktop may cause a build up of heat which may result in damage to the burner grate, burner or cooktop.

Cookware, such as a wok with a support ring, which restricts air circulation around the burner will cause heat to build up and may result in damage to the burner grate, burner or cooktop.

Foods cook faster when the cookware is covered because more heat is retained. Lower the flame size when cookware is covered.

The cooking performance is greatly affected by the type of cookware used. Proper cookware will reduce cooking times, use less energy and produce more even cooking results. For best results use a heavy gauge metal pan with a smooth flat bottom, straight sides and a tight fitting lid.

Cookware with uneven, warped, or grooved bottoms do not make good contact with the heating surface, will reduce heat conductivity and result in slower, less even heating.

To determine the flatness of the bottom of a pan, place the edge of a ruler across the bottom of the utensil. Hold it up to the light. Little or no light should be visible under the ruler.

COOKWARE MATERIAL

The pan material determines how evenly a is conducted from the heat source to the food. The widely used pan materials are:

Aluminum – excellent heat conductor. Soft. Causes it to darken or pit. Often used as a base to improve the heating of other pan materials.

Copper – excellent heat conductor. Discoloration requires constant polishing. Often used as a lining to improve the heating of other pan materials.

Stainless Steel – slow conductor of heat. Causes spots and produces uneven cooking results. Attractive, easy to clean and stain resistant. Heat better if other metals (aluminum or copper) combined or sandwiched together as a bottom.

Cast Iron – slow heat conductor. Cooks even. Temperature is reached. Heavy. Needs seasoning for cleaning easier and to prevent sticking and rust.

Glass – slow heat conductor. Easy to clean. May only be used in the oven.

Porcelain Enamel – glass-like substance. Heating characteristics depend on base material. Easy to clean.

CANNING

Acceptable water-bath or pressure canners should not be oversized and should not rest on two burner grates. They should also have flat bottoms.

When canning, use the HI setting just until the water comes to a boil or pressure is reached in a pressure canner, then reduce to a setting that maintains the pressure or a boil.

Prolonged use of the HI setting, the use of incorrect canning utensils, or the use of improper canning techniques may produce excessive heat and result in permanent damage to the appliance.

NOTE: For additional canning information contact your local County Extension Office. Or, contact Alltrista Consumer Products Company, marketer of Ball brand home canning products at 800-240-3340 or write: Alltrista Corp., Consumer Affairs Dept., P.O. Box 2729, Muncie, IN 47307-0729.


PILOTLESS IGNITION SYSTEM

Be sure oven control is set in the OFF position prior to supplying gas to the appliance.

Your appliance features pilotless ignition. A glo bar will light the oven burner. With this type of ignition system, the oven will not operate during a power failure or if the oven is disconnected from the wall outlet. **No attempt should be made to operate oven during a power failure.**

OVEN BURNER

The size and appearance of a properly adjusted oven burner flame should be as shown:



The oven temperature is maintained by cycling the burner on and off. After the oven temperature has been set, there will be about a 45 second delay before the burner ignites. This is normal and no gas escapes during this delay.

During the clean cycle, and some extended oven cooking operations, you may hear a "popping" sound when the burner cycles off. This is a normal operating sound of the burner.


OVEN VENT

The oven vent is located at the base of the back. When the oven is in use, this area may feel warm to the touch. To prevent baking problems, do not block the vent opening in any way. Also, do not place plastic over the vent opening as heat from the vent could melt the plastic.

GENERAL INFORMATION

- Do not lock oven door during a cooking operation.
 - If the door is locked the LOCK indicator will light and the operation will be canceled. Unlock the door then reset the operation.
- If oven temperature is above 400°F, the interlock locking mechanism will engage and the door will be unlocked until the oven has cooled.
- The oven burner cycles on and off to maintain temperature for baking. The broil burner cycles on and off to maintain temperatures for broiling.

NOTE: Select models do not feature broiling.
- If you press BAKE or BROIL pad and do not see oven temperature or broil setting within 30 seconds, the program will automatically cancel. The time and temperature will reappear in the display.
- To change oven temperature or broil setting during cooking:
 - If temperature is displayed, press ▲ or ▼ pad to select the new temperature.
 - If another function is displayed, press BAKE or BROIL pad then press ▲ or ▼ pad to select new temperature.



ABOUT YOUR RANGE – the oven

HOW TO SET OVEN TO BAKE OR ROAST

1. Press BAKE pad.


- BAKE indicator on the BAKE pad will light.
- 000 will light in display.

BAKE
INDICATOR
LIGHT



2. Press or press and hold ▲ or ▼ pad to select oven temperature.

- 350° will light when either pad is pressed.
- Oven temperature can be set from 170° to 550°.



3. There will be a 4 second delay before the oven turns on. When the oven turns on:

- OVEN ON indicator will light.
- PREHEAT indicator will light.
- The preselected temperature will remain in display.



4. Allow 8 to 15 minutes for the oven to preheat.

- A single beep will indicate that the oven has preheated.
- The OVEN ON indicator will remain lit.
- The PREHEAT indicator will turn off.



5. Place food in the oven.

NOTE: The oven temperature can be changed any time. If the temperature is changed, the PREHEAT indicator will turn back on until the new temperature is reached. A beep will indicate when the new temperature has been reached.

6. Check cooking progress at the minimum cooking time. Cook longer if needed.

NOTE: See pages 13, 14, and 15 for information on baking and roasting.

7. Press CANCEL pad and remove food from the oven.

- The BAKE indicator on the BAKE pad will turn off.
- The OVEN ON indicator will turn off.
- Time of day will reappear in display.



NOTE: If you forget to turn off the oven, it will automatically turn off at the end of the cycle. If you wish to deactivate this energy saving feature, see page 6.

GENERAL BAKING TIPS

Oven characteristics: Each oven has its own personal baking characteristics. Therefore, do not expect that your new oven will perform exactly like your previous oven. You may find that the cooking times, oven temperatures, and cooking results differ somewhat from your previous range. Allow a period of adjustment.

Use a reliable recipe and accurately measure fresh ingredients. **Carefully follow directions** for oven temperature and cooking time.

Use the correct rack position. Baking results may be affected if the wrong rack is used. For optimum results, bake foods on one rack. Select a rack position that locates the food in the center of the oven. If baking on two racks, select rack positions #2 and 4, #1 and 4 or #2 and 5.

- Top browning may be darker if food is located toward the top of the oven.
- Bottom browning may be darker if food is located toward the bottom of the oven.
- When using two racks for baking, allow enough space between the racks for proper air circulation. Browning and cooking results will be affected if air flow is blocked.

Cookware material plays an important part in baking results. Always use the type and size of pan called for in the recipe. Cooking times or cooking results may be affected if the wrong size is used.

- **A shiny metal pan** reflects heat away from the food. This type of pan produces lighter browning and a softer crust. Use shiny pans for baking cakes or cookies.
- **A dark metal, dull, anodized or satin-finish pan** absorbs heat and produces darker browning with a crisper crust. Use dark pans for pies, pie crusts or bread.
- For optimum baking results, bake cookies and biscuits on a **flat** cookie sheet. If the pan has sides, such as a jelly roll pan, browning may not be even.

- If using **heat-proof glassware**, or **dark pans**, **Baker's Secret** or **Wilton** reduce the oven temperature by 25°F except when baking pies or bread. Use the same baking time as called for in the recipe.

Allow hot air to flow freely through the oven for optimum baking results. Improper placement of cookware in the oven will block air flow and may result in uneven browning. For optimum browning and even cooking results:

- Do not crowd a rack with pans. Never place more than one cookie sheet, one 13x9x2-inch cake pan or one 9-inch round cake pans on one rack.
- Stagger pans when baking on two racks so no pan is not directly over another pan.
- Allow two inches between the pan and the oven walls.

Check the cooking progress at the minimum recommended in the recipe. If necessary, continue checking at intervals until the food is done. If the oven door is opened too frequently, heat will escape and this can affect baking results and wastes energy.

If you add additional ingredients or alter the recipe, expect cooking times to increase or decrease.

PREHEATING

Preheating is necessary for baking. Allow about 10 minutes for the oven to preheat. A single beep indicates that the oven is preheated. It is not necessary to preheat for roasting.

Selecting a temperature higher than desired will preheat the oven any faster, and may have a negative effect on baking results.

USE OF ALUMINUM FOIL

Do not cover an entire rack with foil or place foil under cookware. To catch spillovers, place a pie pan a little larger than the pan, on the rack below the pan. Place foil on the oven bottom.

OVEN USE

COMMON BAKING PROBLEMS AND WHY THEY HAPPEN

PROBLEM	POSSIBLE CAUSES
Cakes are uneven.	• Pans too close or touching each other or oven walls. • Batter uneven in pan. • Temperature set too low or baking time too short. • Oven not level. • Uneven oven heating. • Too much liquid.
Cake high in middle.	• Temperature set too high. • Baking time too long. • Overmixing. • Too much shortening or sugar. • Pans touching each other or oven walls. • Incorrect rack position.
Cake falls.	• Too much shortening or sugar. • Too much or too little liquid. • Temperature set too low. • Old or too little baking powder. • Pan too small. • Oven door opened too often. • Added incorrect type of oil to cake mix. • Added additional ingredients to recipe.
Cakes, cookies, biscuits don't brown evenly.	• Incorrect rack position. • Oven door not closed properly. • Door gasket not properly or properly attached to door. • Incorrect use of aluminum foil. • Oven not preheated. • Pans darkened, dented or warped. For optimum results, bake on one rack. If baking cakes on two racks, place the front of the oven on the upper rack and toward the back of the oven on the lower rack.
Cakes, cookies, biscuits too brown on bottom.	• Oven not preheated. • Pans touching each other or oven walls. • Incorrect rack position. • Incorrect use of aluminum foil. • Placed 2 cookie sheets on one rack. • Used glass, dark, stained warped or dull finish metal pans. (Use a shiny cookie sheet.) Follow cookware manufacturer's instructions for oven temperature. Glassware cookware such as Ecco's Baker's Secret may require lowering the oven temperature 25°F.
Cakes don't brown on top.	• Incorrect rack position. • Temperature set too low. • Overmixing. • Too much shortening or sugar. • Pan size too large or too little batter in pan. • Oven door opened too often.
Excessive shrinkage.	• Too little leavening. • Overmixing. • Pan too large. • Temperature set too low. • Baking time too long. • Pans too close to each other or oven walls.
Uneven texture.	• Too much liquid. • Undermixing. • Temperature set too low. • Baking time too short.
Cakes have tunnels.	• Not enough shortening. • Too much baking powder. • Overmixing or at too high speed. • Temperature set too high.
Cake not done in middle.	• Temperature set too high. • Pan too small. • Baking time too short. If additional ingredients were added to mix or recipe, expect cooking time to increase.
Pie crust edges too brown.	• Temperature set too high. • Pans touching each other or oven walls. • Crust too thin; shield with foil.
Pies don't brown on bottom.	• Used shiny metal pans. • Temperature set too low. • Incorrect rack position. • Some frozen pies should be placed on a cookie sheet, check package directions.
Pies have soaked crust.	• Temperature too low at start of baking. • Filling too juicy. • Used shiny metal pans.

ROASTING

Roasting is the method for cooking large, tender cuts of meat uncovered, without adding moisture. Most meats are roasted at 325°F. It is not necessary to preheat the oven. Place the roasting pan on either of the two lowest rack positions.

Use tender cuts of meat weighing three pounds or more. Some good choices are: Beef rib, ribeye, top round, high quality tip and rump roast, pork loin roast, leg of lamb, veal shoulder roast and cured or smoked hams.

Season meat, if desired, either before or after roasting. Rub into the surface of the roast if added before cooking.

Place the meat fat-side-up on a rack in a shallow roasting pan. Placing the meat on a rack holds it out of the drippings, thus allowing better heat circulation for even cooking. As the fat on top of the roast melts, the meat is

basted naturally, eliminating the need for additional basting.

The cooking time is determined by the weight of the meat and the desired doneness. For more accurate results, use a meat thermometer. Insert it so the tip is in the thickest part of the meat. It should not touch the bone.

Remove the roast from the oven when the thermometer registers the desired internal temperature.

NOTE: For more information about food safety, call USDA's Meat & Poultry Hotline at 1-800-535-4589. For cooking information call or write to the National Beef Association, 444 North Michigan Avenue, Chicago, Illinois 60611, or call 1-800-368-3131.

ROASTING CHART (Thawed meats only)

Cut of Meat	Approximate Weight (pounds)	Oven Temperature in °F	Internal Temperature	Approximate Roasting Time (min.)
Beef				
Rib Roast (cut-side-down)	4 to 8	325°F	145°F (medium/rare) 160°F (medium)	25 to 30
Rib Eye Roast	4 to 6	350°F	145°F (medium/rare) 160°F (medium)	25 to 30
Loin Tenderloin Roast	2 to 3	400°F	145°F (medium/rare)	20 to 25
Pork, Fresh				
Shoulder Blade Roast, (boneless)	4 to 6	325°F	160°F	35 to 40
Shoulder Blade Roast	4 to 6	325°F	160°F	30 to 35
Loin Blade or Sirloin Roast	3 to 4	325°F	160°F	35 to 40
Boneless Pork Loin	6 to 8	325°F	160°F	25 to 30
Pork, Smoked				
Ham, Half (fully cooked)**	5 to 7	325°F	140°F	25 to 30
Ham, Half (cook-before-eating)	5 to 7	325°F	140°F	35 to 40
Poultry				
Turkey, unstuffed***	12 to 16	325°F	180°-185°F	18 to 20
	16 to 20	325°F	180°-185°F	16 to 18
	20 to 24	325°F	180°-185°F	14 to 16
Turkey, Breast	3 to 8	325°F	180°F	30 to 35
Chicken, Fryer	2 1/2 to 3 1/2	350-375°	180°F	20 to 25
Chicken, Roaster	4 to 6	350-375°F	180°F	20 to 25
Lamb				
Leg (boneless)	2 to 3	325°F	160°F 170°F	35 to 40
Whole Leg	5 to 7	325°F	160°F	30 to 35

* Cooking times are approximate and may vary depending on the shape of the roast. A meat thermometer is the most accurate way to determine doneness.

** Add water and follow package directions.

*** Stuffed turkey requires additional roasting time. Shield legs and breast with foil to prevent overbrowning and drying of meat.

ABOUT YOUR RANGE – the oven

AUTOMATIC OVEN TIMER CONTROL



CAUTION

- Highly perishable foods such as dairy products, pork, poultry, seafood or stuffing are not recommended for a delayed cooking operation.
- Baking is not recommended because preheating is required.

The clock must be functioning and set at the time of day for this feature to operate properly.


The Automatic Oven Timer Control is used to turn the oven on and off at a preset time of day. This feature can be used for either oven cooking or self-cleaning.

- **Immediate start:** Oven turns on immediately and automatically turns off at a preset time.
- **Delayed start:** Delays the start of cooking and automatically turns off at a preset time.

Cook time can only be set for up to 11 hours and 59 minutes (11:59).


HOW TO SET TIMED COOK OPERATION

1. Press COOK TIME pad.
 - COOK TIME indicator on the COOK TIME pad will flash.
 - 0:00 will light in display.



2. Press or press and hold ▲ or ▼ pad to enter cooking time.

3. Press BAKE pad.
 - BAKE indicator on BAKE pad will light.
 - 000 will light in display.




4. Press or press and hold ▲ or ▼ pad to enter oven temperature.

NOTE: Beeps will sound and 000 will flash in display if the BAKE pad is not pressed within 4 seconds.

5. IF YOU WISH TO DELAY THE START OF COOKING (if not, skip to #6):

- a. Press STOP TIME pad.
 - STOP TIME indicator on STOP TIME pad will flash.
- b. Press or press and hold ▲ or ▼ pad to enter time of day you wish oven to turn off.
- c. Press CLOCK pad.
 - Time of day will reappear in display.



6. When the oven turns on, the OVEN ON indicator will light. The oven temperature will appear in the display. Press the COOK TIME pad to recall the remaining cook time.



NOTE: It is not necessary to set the clock. The Automatic Oven Timer Control will determine when to turn the oven on based on the cook time you set.

7. Oven will automatically turn off. Four beeps will sound and "End" will light in display. A beep will sound every 30 seconds for the next 5 minutes.

NOTE: See page 6 if you wish to change the cooking reminder beeps.


8. Press CANCEL pad and beeps will stop. Remove food from oven.



HOW TO SET OVEN TO BROIL


1. Press BROIL pad.

- BROIL indicator on the BROIL pad will light.
- 000 will light in display.



2. Press the ▲ pad to select HI (high) broil or the ▼ pad to select LO (low) broil.

- Select HI broil for normal broiling.
- Select LO broil for low temperature broiling of longer cooking foods such as poultry.



3. There will be an 8 second delay before the oven turns on. When the oven turns on:

- The OVEN ON indicator will light.





4. Place food in the oven. The oven door is closed for broiling.

NOTE: See page 18 for broiling instructions and broiling chart.

5. Turn meat once about half way through cooking.

6. Press CANCEL pad. Remove food and broiler pan from the oven.

- The OVEN ON indicator will turn off.
- The BROIL indicator on the BROIL pad will turn off.
- Time of day will reappear in display.



NOTE: Select models do not feature broiling. The control panel for these models will not have a BROIL pad.

OVEN USE

BROILING TIPS

Broiling is a method of cooking tender meats by direct heat. The cooking time is determined by the distance between the meat and the broil burner, the desired degree of doneness and the thickness of the meat.

Broiling requires the use of the broiler pan and insert. The broiler insert must be in place to allow fat and liquid to drain to the pan below to prevent spatters, smoke and flare-ups. Improper use may cause grease fires.

For easier clean up, line the broiler pan with foil and spray the insert with a non-stick vegetable spray. Do not cover

the broiler insert with aluminum foil as this prevents fat from draining into pan below.

Trim excess fat and slash remaining fat to help prevent from curling and to reduce smoking and spattering. Season meat after cooking.

Place oven rack in the correct rack position when broiling. For cooler broiling, place meat closer to the burner. Place meat further down if you wish meat to be well done or if excessive smoking or flaring occurs.

See Care and Cleaning Chart on page 21 for instructions on cleaning the broiler pan and insert.

BROILING CHART

TYPE OF MEAT	RACK POSITION*	DONENESS	TO (M)
BACON	#4	Well Done	
BEEF STEAKS 1-inch thick	#4 #4	Medium Well Done	
CHICKEN Pieces	#3 or #4	Well Done	
FISH Fillet Steaks, 1-inch thick	#4 #4	Flaky Flaky	
GROUND BEEF PATTIES 3/4-inch thick	#4	Well Done	
HAM SLICE, precooked 1/2-inch thick	#4	Warm	
PORK CHOPS 1-inch thick	#4	Well Done	

* The top rack position is position #5.

** Broiling times are approximate and may vary depending on the meat.

HOW TO SET OVEN FOR A CLEAN CYCLE

1. Move door lock lever to locked position.



2. Press SELF-CLEAN pad.

- CLEAN indicator on the SELF-CLEAN pad will flash.
- 3:00 will light in display.
- If door is not locked, "dr" will appear in display. Lock door.



3. Press ▲ or ▼ pad to select clean time.


- You can select from 2 up to 4 hours.
- Oven will automatically clean for 3 hours. Or,
 - Select 2 hours for light soil.
 - Select 4 hours for heavy soil.

4. IF YOU WISH TO DELAY THE START OF CLEANING (if not, skip to #5):

- Press STOP TIME pad.
- Press ▲ pad to select the time of day you wish the oven to turn off.
 - Press CLOCK pad and time of day will reappear in display.
 - Press STOP TIME pad to recall the time you set.



then



5. When the oven turns on:

- The OVEN ON indicator will light.
- LOCK indicator will light when oven heats to 400°.
- Internal lock will engage. Door cannot be unlocked and opened when LOCK indicator is lit.




LIGHT TURNS ON WHEN OVEN REACHES 400°

6. About one hour after the clean cycle ends, the LOCK indicator will turn off. The oven door can be unlocked and opened.



TO CANCEL CLEAN CYCLE:

- Press CANCEL pad.
- If LOCK indicator is NOT lit, unlock and open oven door.



WHEN LOCK IS OFF, UNLOCK AND OPEN DOOR

If LOCK indicator is lit, allow oven to cool about one hour then unlock and open oven door.

SELF-CLEAN OVEN



CAUTION

- It is normal for parts of the range to become hot during a clean cycle.
- Avoid touching cooktop, door, window, or oven vent area during a clean cycle.
- To prevent damage to oven door, do not attempt to unlock the door when the LOCK indicator is displayed.

BEFORE CLEAN CYCLE

- Remove pans, broiler pan, and oven racks. Racks may discolor and not slide easily after cleaning.
- Clean oven frame and door frame. These areas are not exposed to cleaning temperatures; soil may bake on during clean cycle.
- To prevent damage, do not clean gasket located on oven door. Gasket seals in heat during the clean cycle.
- To prevent excessive smoke or flare-ups, wipe up excess grease or spillovers from oven bottom.
- Porcelain is acid resistant, not acid proof and may discolor during the clean cycle. To prevent or reduce discoloration, wipe up sugar or acid spills (lemon, milk, barbecue sauce, cheese).

DURING CLEAN CYCLE

- As oven heats, the LOCK indicator will light in the display. At this point, the door can not be unlocked and opened.
- To prevent damage to door or lock lever, do not force door open when the LOCK indicator is displayed.
- Some smoke and odor may be detected the first few times the oven is cleaned. This is normal and will lessen in time.
- Smoke may occur if oven is heavily soiled or if broiler pan was left in oven.
- As oven heats, you may hear sounds of metal parts expanding and contracting. This is normal and will not damage oven.

AFTER CLEAN CYCLE

- The LOCK indicator will go out about one hour after the cycle ends. The door can be unlocked and opened. Use caution; door may still be hot.
- A gray powdery ash may appear on the oven bottom. This is normal. Use a damp cloth to remove ash.
- If soil remains, the door may not have been locked properly.
- Wipe oven racks with a damp cloth. A small amount of vegetable oil may not slide easily after cleaning.
- Clean around oven vent. If there is a deposit from the vent during cleaning, it may affect oven performance.
- Fine lines may appear on the porcelain. This is normal. Results from the heating and cooling of the finish. This will not affect oven performance.

CLEANING TIPS

- ☐ Turn off oven light before cleaning as the light may burn out during a clean cycle.
- ☐ Clean oven regularly rather than allowing soil to build-up.
- ☐ Do not use oven cleaners in, on, or around any part of the range as they will damage the finish or parts.

**CAUTION**

- Be sure appliance is off and all parts are cool before handling or cleaning. This is to avoid damage and possible burns.
- If a part is removed, be sure it is correctly replaced.
- To prevent staining or discoloration, clean appliance after each use.

CLEANING CHART

PARTS	CLEANING AGENTS	CLEANING PROCEDURES
Broiler pan and insert (select models)	• Soap and water • Plastic or soap filled scouring pad • Dishwasher	Never cover insert with aluminum foil as this prevents draining to pan below. 1. Remove from oven after use. Cool then pour off grease. 2. Place soapy cloth over insert and pan; let soak to loosen soil. 3. Wash in warm soapy water. Use soap filled scouring pad to remove stubborn soil. 4. Broiler pan and insert can be cleaned in the dishwasher.
Burner box (conventional surface burners only)	• Soap and water • Paste of baking soda and water • Non-abrasive plastic pad or sponge • Liquid cleaner • Glass cleaner	NOTE: Sealed burner cooktop does not lift up. 1. Burner box, for cooktops with conventional burners, is located under the lift-up cooktop. 2. Clean frequently to remove spillovers. If soil is not removed and allowed to accumulate, it may damage the finish. 3. To clean remove grates and surface burners and clean with water, rinse and dry.
Control knobs	• Soap and water • Mild liquid sprays • Glass cleaners	For ease of cleaning, turn off knob and remove by pulling forward. 1. Wash, rinse, and dry. Do not use abrasive cleaning agents as they will scratch the finish and remove the markings. 2. Turn on each element to be sure knobs have been correctly aligned.
Drip bowls, chrome (select models)	• Soap and water • Plastic scouring pads • Mild abrasive cleaners • Flitz Metal Polish	Do not cover drip bowls with aluminum foil. NOTE: Bowls can permanently discolor over time, if exposed to heat, or if soil is allowed to bake on. The discoloration will not affect cooking performance. 1. After each use, wash, rinse and dry. 2. If heavily soiled, gently scrub with plastic scouring pad. If soil is not removed to burn on, it may be impossible to remove. 3. A non-abrasive metal polish such as Flitz may be used to remove blue/gold heat stains. Flitz is available in many automotive hardware stores. These stains are caused by overheating, and may occur over a period of time. They are usually permanent. Follow directions.

CARE AND CLEANING CHART

PARTS	CLEANING AGENTS	CLEANING PROCEDURES
Enamel, painted - Oven door - Side panels - Storage drawer or lower panel	- Soap and water - Mild liquid cleaner - Glass cleaner	NOTE: Use dry towel or cloth to wipe up spills, especially acid (juice, fruit, mustard, tomato sauce) or sugary spills. Surface may dull if soil is not immediately removed. This is especially important on surfaces. - When cool, wash with warm soapy water, rinse and dry. Do not clean warm or hot surface with a damp cloth as this may damage the surface and may cause a steam burn. - For stubborn soil, use mildly abrasive cleaning agents such as soda paste or Bon Ami. - Do not use abrasive, caustic or harsh cleaning agents such as scouring pads or oven cleaners. These products will scratch or pockmark and damage the surface.
Glass Oven window	- Soap and water - Glass cleaner - Paste of baking soda and water	To prevent staining of the oven window, avoid using excessive amounts of water which may seep under or behind glass. - Wash with soap and water. Remove stubborn soil with paste of baking soda and water. Rinse with clear water and dry. - Do not use abrasive materials such as scouring pads, steel wool or powdered cleaning agents. They will damage glass.
Grates	- Soap and water - Non-abrasive plastic pad	NOTE: Never operate burner without a grate in place. To protect the porcelain finish on the grate from excessive heat, never operate a burner without a cooking utensil on the grate. It is normal for grates to lose their shine over a period of time. - Grates are made of porcelain-coated steel. They can be cleaned in the sink with soap and water or in the dishwasher. - To clean baked on soil, place a damp soapy paper towel over the soil and let stand for 30 minutes. Use a non-abrasive plastic pad to remove stubborn soil.
Metal finishes such as brushed aluminum, or chrome - Backguard - Cooktop - Manifold panel - Oven door - Storage door - Trim parts	- Soap and water - Glass cleaner - Plastic or non-abrasive pad or sponge	- Wash with soap and water or a glass cleaner and a soft cloth. - To prevent scratching or dulling of the finish, do not use mild abrasives, or harsh cleaners, or caustic cleaners such as oven cleaners. - To clean brushed aluminum: Use only soap and water or a mild glass cleaner to prevent scratching or dulling of the finish. - To clean brushed chrome cooktop or door: - Use a paste of baking soda and water and a soft cloth. - Rub with the grain to prevent scratching, dulling or streaking the finish. - Use a soft cloth and mineral oil to restore luster or to remove fingerprints or smudges. - Clean with an automotive chrome cleaner or polisher.
Oven interior		Porcelain enamel is acid resistant, not acid proof. Therefore, wipe up sugary or acid spills (milk, fruit, tomato, etc.) as they occur. See pages 19-20 for self-clean oven.
Oven racks	- Soap and water - Plastic scouring pad - Cleansing powders - Soap-filled scouring pad	- Clean with soapy water. - Remove stubborn soil with cleansing powder or soap-filled scouring pad. Rinse and dry. Racks will permanently discolor and may not slide smoothly if left in place during a self-clean operation. If this occurs, wipe the rack and rack supports with a small amount of vegetable oil to restore movement, then wipe off excess oil.

PARTS	CLEANING AGENTS	CLEANING PROCEDURES
Plastic finishes • Door handles • Backguard trim • Knobs • End caps	• Soap and water • Non-abrasive plastic pad or sponge • Glass cleaner	NOTE: To prevent staining or discoloration, wipe up fat, grease (tomato, lemon, vinegar, milk, fruit juice, marinade) immediately with a paper towel or cloth. 1. When cool, clean with soap and water, rinse, and dry. 2. Use a glass cleaner and a soft cloth. NOTE: Never use oven cleaners, abrasive or caustic liquid cleansers on plastic finishes. These cleaning agents will scratch the finish.
Porcelain enamel • Cooktop • Backguard	• Soap and water • Paste of baking soda and water • Non-abrasive plastic pad or sponge	Porcelain enamel is glass fused on metal and may crack or chip. It is acid resistant, not acid proof. All spillovers, especially around the vent opening for smoothtop cooktop, should be wiped up immediately with a dry cloth. This prevents discolor or dull if soil is not removed. 1. When cool, wash with soapy water, rinse and dry. 2. Never wipe off a warm or hot surface with a damp cloth. This causes cracking and chipping. 3. Never use oven cleaners, abrasive or caustic cleaning agents on the finish of range.
Surface burners • Conventional • Sealed	• Soap and water • Paste of baking soda and water • Plastic scouring sponge or pad • Mildly abrasive cleanser	All burners: For ease of cleaning, clean burners each time they are used with warm soapy water. If a boilover occurs, remove pan and burner; cool burner and clean. To remove stubborn soil, use a mild, mildly abrasive cleanser. Use care to prevent cleaner from clogging burner. Burner must be dry before use. NOTE: Yellow tipping or discoloration of flame may occur until the burner is completely dry. Clean burner ports with a straight pin or small metal paperclip. Do not enlarge or distort ports. Do not use a wooden toothpick as it may break and clog port. If ports are clogged or soiled, the burner may not light or the flame may not be even. Conventional burners: Dry burners in the oven set at 170°F. Sealed burners: Sealed burner can not be removed by the user. When cleaning burner, use care to prevent damage to the ignitor. burner will not light properly if ignitor is damaged, broken, soiled. When cleaning the ports, be sure to clean the port directly below the burner.

ABOUT CLEANING PRODUCTS

READ THE MANUFACTURER'S INSTRUCTIONS to be sure the cleaner can be safely used on this appliance. Carefully follow manufacturer's directions.

Test a small inconspicuous area using a very light pressure to see if the surface may scratch or discolor. This is particularly important for porcelain enamel, highly polished or shiny metal or plastic surfaces, and painted surfaces.

Glass Cleaners – Bon Ami, Cinch, Glass Plus, Windex.

Dishwashing Liquid Detergents – Dawn, Dove, Ivory, Joy.

Mild Liquid Spray Cleaners – Fantastik, Formula 409.

Non-Abrasive Cleaners – Bon Ami, paste of baking soda and water.

Mildly Abrasive Powder or Liquid All Purpose Cleansers – Ajax, Barkeepers Friend, Cameo, Soft Scrub.

Non-Abrasive or Scratchless Plastic or Nylon Scouring Pads or Sponges – Chore Boy Plastic Cleaning Puff, Scrungie Scrub Sponges, or Scotch-Brite No Scratch, Cookware or Kitchen Sponge.

Abrasive Scouring Pads – S.O.S., Brillo Steel Wool Soap, Scotch-Brite Pads.


(Brand names for the above cleaning products are trademarks of the respective manufacturers.)

MAINTENANCE

COOKTOP - CONVENTIONAL BURNERS

The cooktop featuring conventional surface burners lifts up for easy cleaning of the burner box area.


To raise the "lift-up" cooktop: When cool, grasp the front edge of the cooktop and gently lift up until the two support rods at the front of the cooktop snap into place.



To lower the top: Hold the front edge of the cooktop and carefully push back on each support rod to release the notched support. Then gently lower the top into place. The support rods will slide into the cooktop frame.

COOKTOP - SEALED BURNERS

The sealed burner cooktop is designed with two contour wells to catch and contain spills. Because of this design it is not necessary to lift up the cooktop to clean underneath. To prevent damage to the gas tubing or top, do not attempt to lift or remove the cooktop.



BURNER GRATES

Burner grates must be properly positioned before cooking. Burner grates are durable but may gradually lose their shine due to usage and high temperatures.

Grates for the porcelain cooktop are square. When installing square grates, place indented sides together so straight sides are at front and rear.

CAUTION: Do not operate a surface burner pan on the grate. The porcelain finish on the chip without a pan to absorb the intense heat of the burner flame.


OVEN LIGHT

CAUTION: Before replacing the light bulb, DISCONNECT POWER TO RANGE. Be sure the range is cool. Do not touch a hot bulb with a damp cloth. The bulb may break.

To turn on oven light: Push the rocker switch on the backguard.

To replace oven light bulb:

1. Disconnect power to range.
2. Hold bulb cover in place then slide wire retainer over cover. **NOTE:** Bulb cover will fall if not held while removing wire retainer.
3. Remove bulb cover.
4. Remove light bulb and replace with a 40 watt bulb.
5. Replace bulb cover and secure with wire retainer.
6. Reconnect power to range. Reset clock.



OVEN DOOR


Do not place excessive weight on an open oven door or stand on an open oven door as, in some cases, it could cause the range to tip over, break the door or cause serious injury to the user.

When opening the oven door, allow steam and hot air to escape before reaching in oven to check, add or remove food.

Do not attempt to open or close door until the door is completely seated on the hinge arms. Never turn on the oven unless door is properly in place. When baking, be sure the door is completely closed. Baking results will be affected if the door is not securely closed.

When the range is new the door may feel "spongy" when you close the door. This is normal and will become less "spongy" with use.

To remove lift-off door: Open the door to the "stop" position (opened about 6 inches) and grasp the door with both hands at each side. Do not use the door handle to lift the door. Lift up evenly until the door clears the hinge arms.



To replace door: Grasp the door at each side, align slots in the door with the hinge arms and slide the door down onto the hinge arms until door is seated on hinges. Push down on top corners of door to completely seat door on hinges. The door is not completely seated on the hinges if one side is higher or if the door appears to be crooked.

CAUTION: Hinge arms are spring mounted and will slam shut against the range if accidentally hit. **Never place hand or fingers between the hinges and the front oven frame.** You could be injured if hinge snaps back.

DOOR LOCK LEVER


The oven door is locked for a self-clean operation. You cannot move the door lock lever to the right or left during a cooking operation. If the door is locked, the self-clean operation will automatically be cancelled and the lock indicator will appear in the display. If the oven is hot enough to engage the internal lock, the oven door will not open until the oven has cooled to cool for up to an hour, then unlock the door.

OVEN BOTTOM

Protect oven bottom against excessive spills of oil, grease, acid or sugary spillovers as they may discolor or damage the oven bottom.

To protect oven bottom:

- Use the correct size cooking utensil to avoid scratching the oven bottom.
- Never place cookware or aluminum foil directly on the oven bottom.
- Place a piece of aluminum foil that is slightly larger than the pan on the oven rack directly below the pan.



To remove: When cool, remove the oven bottom. Lift the rear edge of the oven bottom slightly and push the front edge of the oven bottom back until the front edge of the oven bottom is seated on the front frame. Remove oven bottom from oven.

Lift the rear edge of the oven bottom slightly and push the front edge of the oven bottom back until the front edge of the oven bottom is seated on the front frame. Remove oven bottom from oven.

To replace: Fit the front edge of the oven bottom into the front frame. Lower the rear of the oven bottom until the rear edge of the oven bottom is seated on the rear frame. Push the front edge of the oven bottom back to lock the oven bottom.

MAINTENANCE

OVEN RACKS

The two oven racks are designed with a safety lock-stop position to keep the racks from accidentally coming completely out of the oven when pulling the rack out to add or remove food.

CAUTION: Do not attempt to change the rack positions when the oven is hot.

To remove: Be sure the rack is cool. Pull the rack straight out until it stops at the lock-stop position. Tilt the front end of the rack up and continue pulling the rack out of the oven.

To replace: Place the rack on the rack supports and tilt the front end of the rack up slightly. Slide it back until it clears the lock-stop position. Lower the front and slide the rack straight in. Pull the rack out to the lock-stop position to be sure it is positioned correctly and then return it to its normal position.

It is important that air can circulate freely with and around the food. To help ensure this, place the center of the oven rack. Allow two inches between the edge of the utensil(s) and the oven walls.

For optimum baking results of cakes, cookies, etc., use one rack. Position the rack so the food is in the center of the oven. Use either rack position 3 or 2.


If cooking on more than one rack, stagger the food to ensure proper air flow.

If cooking on two racks, use rack positions 4 and 1 when using cookie sheets. Never place two cookie sheets on one rack.

If roasting a large turkey, place the turkey on the top rack in the roasting position and the side dishes on rack 1.


RACK POSITIONS

RACK 5 (highest position)	Used for toasting bread, or for two-rack baking.
RACK 4	Used for most broiling and two-rack baking.
RACK 3	Used for most baked goods on a cookie sheet or jelly roll pan, or frozen convenience foods.
RACK 2	Used for roasting small cuts of meat, large casseroles, baking loaves of bread, cakes (in either tube, bundt, or layer pans) or two-rack baking.
RACK 1	Used for roasting large cuts of meat and large poultry, pies, souffles, or angel food cake, or for two-rack baking.
ROASTING POSITION	Used for roasting taller cuts of meat or turkey. Place both oven racks, one above the other, on the raised sides of the oven bottom.



STORAGE DRAWER

The storage drawer at the bottom of the range is safe and convenient for storing metal and glass cookware. DO NOT store plastic, paperware, food or flammable material in this drawer. Remove drawer to clean under range.




To remove: Pull drawer out to the first stop position. Lift up front of drawer and pull to the second stop position. Grasp sides and lift up and out.

To replace: Fit the rollers located at the ends of the drawer glides into the rails on the range. Lift up drawer front and gently push in to first stop position. Lift up drawer again and continue to slide drawer to the closed position.

LEVELING LEGS

Some floors are not level. For proper baking, your range must be level. Leveling legs are located on each corner at the base of the range. Level by turning the legs. To prevent range from accidentally tipping, range should be secured to the floor by sliding a rear leveling leg into the anti-tip bracket supplied with the range.

**HOW TO REMOVE RANGE FOR AND SERVICING**

Follow these procedures to remove appliance for servicing:

1. Shut-off gas supply to appliance.
2. Disconnect electrical supply to appliance.
3. Disconnect gas supply tubing to appliance.
4. Slide range forward to disengage range from bracket. (See Installation Instructions for bracket.)
5. Reverse procedure to reinstall. If gas line disconnected, check for gas leaks after reinstallation. A qualified service technician should disconnect and reconnect gas supply. (See Installation Instructions for test method.)

NOTE: A qualified service technician should disconnect and reconnect the gas supply.


To prevent range from accidentally tipping, range should be secured to the floor by sliding rear leveling leg into the anti-tip bracket supplied with the range.

WARNING: Possible risks may result from misuse, including excessive loading of the range and of the risk of tip over, should the appliance be reinstalled according to the installation instructions.

SERVICE INFORMATION

ELECTRICAL CONNECTION

Appliances which require electrical power are equipped with a three-prong grounding plug which must be plugged directly into a properly grounded three-hole 120 volt electrical outlet.




The three-prong grounding plug offers protection against shock hazards. **DO NOT CUT OR REMOVE THE THIRD GROUNDING PRONG FROM THE POWER CORD PLUG.**

If an ungrounded, two-hole or other type electrical outlet is encountered, **it is the personal responsibility of the appliance owner to have the outlet replaced with a properly grounded three-hole electrical outlet.**

PROPORTIONAL VALVE ADJUSTMENT

The LOW setting should produce a stable flame turning the knob from HI to LO. The flame should be 1/2 inch or lower and must be stable on all ports setting.

To adjust: Operate burner on HI for about 5 minutes to preheat burner cap. Turn knob back to LO; remove burner cap and insert a small screwdriver into the center of the gas valve stem. Adjust flame size by turning adjustment screw in either direction.



Flame must be of sufficient size to be stable on all ports. If flame adjustment is needed, adjust the knob to the LOW setting. Never adjust flame size on a high setting.


NOTE: All gas adjustments should be done by a qualified service technician only.

OVEN TEMPERATURE ADJUSTMENT


You can adjust the oven temperature if you feel the temperature is too hot or too cool.

To adjust the oven temperature:

1. Press BAKE pad.
2. Press ▲ pad until 550° is displayed.
3. Press and hold BAKE pad for 3 seconds until 00° appears in display.



4. Press and hold the ▲ or ▼ pad to select the temperature change you wish.
 - The oven temperature can be increased or decreased by 5° to 35°.
 - If the oven temperature was previously adjusted, the change will be displayed.



For example: If the oven temperature was reduced by 15°, the display will show - 15°.

5. Time of day will automatically reappear in display.

It is not necessary to readjust the oven temperature if there is a power failure or interruption. Broiling and cleaning temperatures cannot be adjusted.

EXPLANATION OF FAULT CODES

If a fault code appears in the display and continuous beeps sound, press the CANCEL pad. Then, reprogram the cooking operation. If the fault code reappears in the display, call an authorized servicer. Do not use the oven until the appliance has been serviced.

NOTE: If the oven is heavily soiled, excessive smoke and flaring may result in a fault code during a self-clean cycle. If this occurs, press the CANCEL pad and allow the oven to cool for an hour.

HOW TO RECEIVE SERVICE

Do not attempt to service the appliance yourself. If you are directed to do so in this manual. Contact the dealer or call you the appliance for service.

1. Contact your dealer or authorized service center. If you do not know the dealer, consult the Yellow Pages or telephone directory under APPLIANCES, 1-800-688-1120.
2. When requesting information or service, the following information will be needed.
 - a. Model and serial numbers. (See rating label on the range front frame.)
 - b. Your name, address and telephone number.
 - c. Dealer or servicer's name, address and telephone number.
 - d. Brief description of the problem and symptoms.
 - e. For warranty service, proof of purchase (receipt) will be needed.
3. If you are not able to satisfactorily resolve the problem with the local response, call or write to:

Maytag Customer Service
P.O. Box 2370
Cleveland, TN 37320-2370
1-800-688-1120

4. If you still do not receive satisfactory service, contact the Major Appliance Consumer Action Program. Include the information listed in #2.

Major Appliance Consumer Action Program
20 North Wacker Drive
Chicago, IL 60606

MACAP is an independent agency sponsored by national trade associations as a court of appeals on consumer complaints which have not been resolved satisfactorily within a reasonable period of time.

SERVICE INFORMATION

TROUBLESHOOTING CHART

PROBLEM	POSSIBLE CAUSES	SUGGESTED CORRECTIONS
Surface burner fails to light	a. power supply not connected b. air in the gas line c. clogged burner port(s) d. surface control not completely turned to the LITE position or turned too quickly from the LITE position e. power failure f. sealed burner models: Burner will not light if the ignitor is damaged, soiled, wet or if the port directly below the ignitor is blocked.	a. connect power, check circuit breaker or fuse box b. see page 7 for instructions on bleeding air from the gas line c. clean ports with straight pin d. turn control to the LITE position, the burner ignites, then turn to desired flame size e. see page 7 to light burner if power failure f. clean and dry burner head or damaged, call a serviceman
Burner flame uneven	a. clogged burner port(s)	a. clean ports with straight pin
Surface burner flame • lifts off port • yellow in color	a. air/gas mixture not proper b. no pan in place NOTE: Lifting of flame is normal for sealed burners. Some yellow tipping with LP gas is normal and acceptable.	a. call serviceman to adjust b. always place pan on gas lighting burner. NOTE: Be sure installers adjusted range at time of installation.
Surface burner ignitor producing clicking sound	a. control knob is in the LITE position. NOTE: The life of the ignition system may be shortened if the knob is left in the LITE position. b. surface control switch is moist as a result of cleaning the range. c. malfunctioning switch	a. be sure ALL surface burner knobs are in the OFF position and adjusted to the desired flame setting b. allow switch to dry the next time you clean the burner c. call serviceman to check
Oven burner fails to light	a. power supply not connected b. power failure c. oven incorrectly set d. Automatic Oven Cooking feature incorrectly set	a. connect power, check circuit breaker or fuse box b. oven will not operate if power failure c. See pages 5 or 12 d. See page 16
Popping sound heard when burner extinguishes	This is a normal sound that occurs with some types of gas when a hot burner is turned off. The popping sound is not a safety hazard and will not damage the burner.	
Clock and/or oven light does not work	a. power supply not connected b. bulb may be loose or burned out c. malfunctioning switch, starter or ballast d. malfunctioning clock or loose wiring	a. connect power supply, check circuit breaker or fuse box b. tighten or replace light bulb c. call serviceman to check d. call serviceman to check

TROUBLESHOOTING CHART

PROBLEM	POSSIBLE CAUSES	SUGGESTED CORRECTIONS
Moisture condensation on oven window	a. it is normal for the window to fog during the first few minutes the oven is on b. cloth saturated with water is used to clean the window	a. leave door ajar for one minute to allow moisture to escape b. Use a damp cloth to clean the window to prevent excess water from seeping between the panels of the window
Baking results not satisfactory • food takes too long or cooks too fast • pale browning • food over-done on outside and under-done in center • over browning	a. oven not preheated b. incorrect rack position c. incorrect use of aluminum foil d. oven bottom incorrectly replaced e. door incorrectly replaced	a. preheat oven 8 to 15 minutes b. see page 26 c. see page 13 d. replace oven bottom e. see page 25 See Problem Chart on page 25 See baking tips on page 25
Oven smokes excessively during a broil operation	a. food too close to burner b. meat has too much fat c. sauce applied too early or marinade not completely drained d. soiled broiler pan e. broiler insert covered with aluminum foil	a. move broiler pan down to correct position b. trim fat c. apply sauce during last 10 minutes of cooking. If meat has been marinated, drain thoroughly before cooking d. always clean broiler pan after each use e. never cover insert with foil. This prevents fat from dripping down below
"F" plus a number or letters appear in display. 	This is called a FAULT CODE. If a fault code appears in the display and beeps sound, disconnect power to the appliance and call an authorized servicer. If the oven is heavily soiled, excessive flare-ups may result in a fault code during the clean cycle. Press any pad except the CANCEL and ▲ or ▼ pads and allow oven to cook for 1 hour then reset the clean cycle.	

BROILING CHART

The times given in the chart should be used only as a guide. Increase or decrease broiling times to suit individual taste for doneness.

FOOD	THICKNESS & QUANTITY	DONENESS	SIDE 1	MIN. COOK TIME SIDE 2	TOTAL
Bacon	8 slices	crisp more crisp	3 5	2 3	5 8
Beef Steaks	3/4"	rare medium well	5-6 7-8 10-11	3-4 3-5 6-8	8-10 10-13 16-19
Beef Steaks Frozen	1"	rare medium well	6-7 8-9 16-17	4-5 6-7 10-12	10-12 14-16 26-29
Beef Steaks Fresh	1 1/2"	rare medium well	8-9 11-12 18-20	6-8 10-12 15-18	14-17 21-29 33-38
Chicken Broiler Split & Quartered		180° internal	20 skin down	15 skin up	35
Fish Fillets Fresh Frozen	1" 1"		6-7 8-9	4-5 5-7	10-12 13-16
Hamburger Fresh	1/2"	rare medium well	5-6 6-7 9-10	4-5 4-5 5-6	9-11 10-12 14-16
Hamburger Frozen	1/2"	medium	9-10	5-6	14-16
Ham slice precooked	3/4"	150-160 internal	9-10	7-8	16-18
Lamb Chops Fresh Frozen	3/4"	medium well medium	6-8 8-9 8-9	3-5 6-7 6-7	9-13 14-16 14-16
Liver-Fresh	1/2" - 3/4"		4	3-4	7-8
Lobster Fresh	7 oz.		shell up 7-8	shell down 6-7	13-15
Frozen			14-16	11-12	25-28

COOKING TERMS

BAKING POWDER - A leavening agent which makes foods rise when they are baked. It is a combination of baking soda, a dry acid or acid salt and starch or flour. The acid ingredient reacts with the baking soda to produce gas bubbles in the mixture. Double-acting baking powder produces gas bubbles twice: first during mixing and second during baking.

BAKING SODA - An essential ingredient of baking powder, may be used alone as a leavening agent in mixtures containing an acid ingredient such as buttermilk or in combination with baking powder. Mixtures containing baking soda should be baked as soon as mixed, since the soda starts to react as soon as it comes in contact with the liquid.

BARBECUE - To roast or broil food on a rack or spit over coals, or under a heat unit. The food is usually brushed with a highly seasoned sauce during the last of the cooking time.

BATTER - A mixture of fairly thin consistency, made of flour, liquid and other ingredients.

BEAT - To make a mixture smooth with rapid, regular motion using a wire whisk, spoon, hand beater or mixer. When using a spoon, the mixture should be lifted up and over with each stroke.

BLEND - To mix thoroughly two or more ingredients; or to prepare food in blender until pureed, chopped, etc., as desired.

BREAD - To coat with bread crumbs, cracker crumbs or cornmeal. Food may first be floured, then dipped in beaten egg or other liquid to help crumbs to adhere.

BROIL - To cook food by direct heat on a rack or spit.

BRUSH WITH - To use a pastry brush to spread food lightly with liquid such as salad oil, melted fat, milk, heavy cream or beaten egg.

CHOP - To cut food into small pieces with a knife, blender or food processor.


COAT - To sprinkle food with, or dip it into, flour, sauce, etc., until covered.

CUBE -

1. To cut food into small cubes (about ½ inch).
2. To cut surface of meat in checkered pattern to increase tenderness by breaking tough meat fibers.


CUT IN - To distribute solid fat in flour or flour mixture by using pastry blender or two knives scissor-fashion until flour-coated fat particles are of desired size.

DICE - To cut food into very small pieces (about 1/4 inch).



DICING AN ONION - Cut onion in half lengthwise, with cut side down, cut onion crosswise in 1/4 inch thick slices.

Hold onion firmly and give quarter turn; cut in 1/4 inch pieces. Repeat with other onion half.



TERMS

DRAW - To remove entrails from, and clean, poultry or game. Drawn fish are whole fish that have been cleaned (eviscerated) but not boned.

DOT - To scatter bits, as of butter or margarine, over surface of food.

DREDGE - To cover or coat food, as with flour, cornmeal, etc.

DRESS - To mix salad or other food with dressing or sauce.

DRIPPINGS - Fat and juice given off by meat or poultry as it cooks.

FLAME - To ignite warmed alcoholic beverage poured over food. Also known as flambe.

FLOUR - 1. *All-purpose*. Made from a variety of wheats, it produces good results for a wide variety of baked goods. *Whole-wheat flour* is milled from the entire wheat kernel while *rye flour* is milled from the rye kernel. *Cake flour* is milled especially for cakes and other light baked products. For best results always use the flour called for in the recipe. In recipes calling for all-purpose and whole wheat or rye, a certain proportion of all-purpose to the other flour is needed for best results; so don't substitute flour. 2. To coat lightly with flour.

FLUTE - To make decorative indentations.

FOLD IN - To combine delicate ingredients such as whipped cream or beaten egg whites with other foods by using a gentle, circular motion to cut down into the mixture, slide across the bottom of the bowl to bring some of the mixture up and over the surface.

FONDUE - Most often a dish of hot melted cheese and wine, into which bread is dipped and then eaten. For meat fondues, at the table, cubes of meat are dipped in hot fat to cook,

then into a choice of sauces. Dessert fondues include chocolate or other sauces for dipping chunks of poundcake or fruit. The term also denotes a baked main dish made with cheese, milk and bread.

GELATIN - Available as unflavored and fruit-flavored. They are not interchangeable.

GLACE - 1. Glazed, as with a frosting. 2. Frozen.

Glaze. 1. To coat with a glossy mixture. 2. Concentrated stock used to add flavor.

GRATE - To rub food on a grater (or chop in blender or food processor) to produce fine, medium or coarse particles.

GRATIN - A French term defining a brown crust formed by baking or broiling bread crumbs, cheese, butter or a mixture on top of a casserole or other dish.

GREASE - To rub surface of dish or pan with fat, to keep food from sticking.

GARNISH - To add a decorative touch to food, as with parsley, croutons or prepared vegetables.

GRILL - To cook food on a rack by direct heat; also the appliance or utensil used for this type of cooking.

GRIND - To reduce to particles in food grinder, blender or food processor.

KNEAD - To work a food mixture (usually dough) with a press-fold motion.

LUKEWARM - At a temperature of about 95°F. Lukewarm food feels neither warm nor cold when in contact with inside of the wrist.

MARbled - Term used to describe meat with visible fat running through the lean.

TERMS

MARGARINE - Comes in several forms. Regular margarine with 80 percent fat is interchangeable with butter in recipes.

MARINADE - A seasoned liquid, in which food is soaked to enhance flavor.

MARINATE - To soak in a marinade.

MEAT TENDERIZER - Papain from natural tenderizers such as papaya is used to soften meat tissue. It is usually sprinkled on the meat before meat is cooked.

MERINGUE - Mixture of stiffly beaten egg whites and sugar. Also the cooked soft mixture on desserts or the cooked "hard" mixture as a dessert shell.

MINCE - To cut into very small pieces, using knife, food grinder or blender, or food processor.

PEEL - To remove outer covering of foods by trimming away with knife or vegetable peeler, or by pulling off.

POT-ROAST - To cook large pieces of meat or poultry by braising; also certain meat cuts.

PREHEAT - To heat oven to desired temperature before putting food into bake.

PUNCH-DOWN - To deflate a risen yeast dough by pushing it down with the fist.

PUREE - 1. A thick mixture made from a pureed vegetable base. 2. To press food through a fine sieve or food mill, or to blend in blender or food processor to a smooth, thick mixture.

PIT - To remove seed from whole fruit.

SCORE - 1. To cut shallow slits in surface of food to increase tenderness or to prevent fat covering from curling. 2. To decorate.

SHRED - To cut food into slivers or slender pieces, using a knife or shredder.

SHUCK - To remove meat of oysters, clams, etc. from their shells or to remove the husk from corn.

SKIM - To remove fat or scum from surface of food.

TOSS - To mix foods lightly with a lifting motion, using two forks or spoons.

TRUSS - To secure poultry with string or skewers, to hold its shape while cooking.

VINEGAR - An acid liquid used for flavoring and preserving. Among the types: Cider vinegar, made from apple juice, has a mellow fruit flavor; distilled white vinegar, usually made from grain alcohol; herb vinegars flavored with herbs; and red or white wine vinegars which also may be flavored with garlic.

WHIP - To beat rapidly with mixer, wire whisk or hand beater, to incorporate air and increase volume.

YEAST - Micro-organisms that produce carbon dioxide and alcohol from carbohydrates to cause baked goods to rise, fruits to ferment, etc.

EQUIVALENT MEASURES

Dash	2 to 3 drops or less than 1/8 teaspoon
1 tablespoon	3 teaspoons
1/4 cup	4 tablespoons
1/3 cup	5 tablespoons plus 1 teaspoon
1/2 cup	8 tablespoons
1 cup	16 tablespoons
1 pint	2 cups
1 quart	4 cups
1 gallon	4 quarts
1 peck	8 quarts
1 bushel	4 pecks
1 pound	16 ounces

BAKING PAN EQUIVALENTS

4 - CUP BAKING DISH:

9 inch pie plate
 9 x 1 1/4 inch layer cake pan
 7 3/8 x 3 3/8 x 2 1/4 inch loaf pan

6 - CUP BAKING DISH:

8 or 9 x 1 1/2 inch layer cake pan
 10 inch pie plate
 8 1/2 x 3 1/8 x 2 2/8 inch loaf pan

8 - CUP BAKING DISH:


8 x 8 x 2 inch square pan
 11 x 7 x 1 1/2 inch baking pan
 9 x 5 x 3 inch loaf pan

10 - CUP BAKING DISH:



9 x 9 x 2 inch square pan
 11 3/4 x 7 1/2 x 1 3/4 inch baking pan
 15 x 10 x 1 inch jelly roll pan





12 - CUP BAKING DISH AND OVER:



13 1/2 x 8 1/2 x 2 inch glass baking pan - 12 cups
 13 x 8 x 2 inch metal baking pan - 15 cups
 14 x 10 1/2 x 2 1/2 inch roasting pan - 19 cups



CAUSE & CORRECTION

PROBLEM	CAUSE	CORRECTION
BROWNING: Uneven bottom browning	1. Dented or warped pan. 2. Oven not preheated. 3. Range not level.	1. Use even bottomed pan. 2. Preheat to desired temp. before adding food. 3. Adjust leg levelers (see Use and Care).
Too brown on bottom 	1. Improper rack placement. 2. Oven door has been opened too often. 3. Oven not preheated. 4. Pans touching walls or other pans. 5. Warped, dark or dull finished pan (include glass).	1. Check for correct rack position before starting while oven is cold. 2. Open door only after food has been baked for shortest recommended baking time. 3. Preheat to desired temp. before adding foods. 4. Pans should not be closer than 1½ to 2 inches from each other or oven walls. 5. Use even bottomed, shiny pans for light browning.
Too brown on top. 	1. Oven doors open too often. 2. Overmeasuring. (fats-sugars-liquids). 3. Oven temp. too low. 4. Pan size too large.	1. Open door only after food has been baked for shortest recommended baking time. 2. Use standard measuring cups. 3. Double check recipe for correct oven temperature. 4. Use pan size recommended in recipe.
Crack on top.	1. Oven temperature too high. 2. Overmeasuring.	1. Double check recipe for correct oven temperature. 2. Use standard measuring cups.
Crumbly or dry. 	1. Oven temp. too high. 2. Over baking. 3. Over measuring.	1. Double check recipe for correct oven temp. - excess heat dries food. 2. Check foods after shortest baking time. 3. Use standard measuring cups.

PROBLEM	CAUSE	CORRECTION
Fallen 	1. Oven door opened too soon. 2. Oven temperature too low. 3. Old or too little baking powder. 4. Too much batter or too little pan. 5. Too much or too little liquid. 6. Under baked.	1. Check food only after the shortest recommended baking time. 2. Check recipe for correct oven temperature. 3. Use standard measuring utensils. 4. Use correct pan size. 5. Use standard measuring utensils. 6. Check food after shortest recommended baking time.
Flat 	1. Improper rack placement. 2. Old or too little baking powder. 3. Oven temperature too high or too low. 4. Pan too large for amount of batter. 5. Too much or too little liquid.	1. Check rack position, before starting and while oven is still cold. 2. Use standard measuring utensil. 3. Check recipe for correct oven temp. and correct type of utensil (glass utensils) require lower temperature. 4. Use recommended baking utensil. 5. Use standard measuring utensil.
Mound or peaked center 	1. Baking time too long. 2. Oven temperature too high. 3. Pan too large or too small. 4. Pans touching walls or other pans. 5. Too little liquid.	1. Check food after shortest recommended baking time. 2. Check recipe for correct oven temperature. 3. Use recommended baking utensil. 4. Pans should not be closer than 1½ to 2 inches. 5. Use standard measuring utensils.
Shrinkage (more than necessary). 	1. Baking time too long. 2. Oven temperature too high. 3. Pans touching walls or other pans.	1. Check food after shortest recommended baking time. 2. Check recipe for correct oven temperature. 3. Pans should not be closer than 1½ to 2 inches.

PROBLEM	CAUSE	CORRECTION
Uneven top 	1. Pans touching walls or other pans. 2. Oven temperature too low. 3. Range not level. 4. Too much liquid. 5. Underbaking. 6. Undermixing.	1. Pans should not be closer than 1½ to 2 inches. 2. Check recipe for correct oven temperature 3. Adjust leg levelers (consult Use and Care Manual). 4. Use standard measuring utensils. 5. Check food after shortest recommended baking time. 6. Check recipe.
Uneven texture holes and tunnels. 	1. Baking time too short. 2. Improper rack placement. 3. Not baking immediately after mixing. 4. Oven temperature too high. 5. Too much baking powder. 6. Undermixing.	1. Check foods after shortest recommended baking time. 2. Check rack position before starting and while oven is cold. 3. Always bake immediately. 4. Check recipe for correct oven temperature. 5. Use standard measuring utensils. 6. Use standard measuring utensils.

SERVICING

BEFORE YOU CALL A SERVICE TECHNICIAN CHECK THE FOLLOWING

SOME OR NONE OF YOUR RANGE OPERATES:

- _____ Is your range plug disconnected from the electrical outlet?
- _____ Are your house fuses blown?
- _____ Is your circuit breaker tripped?
- _____ Is the range plug loose or improperly plugged?

ELEMENT WON'T HEAT: (SURFACE UNITS ONLY)

- _____ Are your elements properly in place?
- _____ Are element prongs bent or dirty?

BAKED GOODS NOT TURNING OUT:

- _____ Are your racks properly in place and in correct position for what you are baking?
- _____ Is your range level? (Check leg levelers).
- _____ Are you using the proper pan? Is it bright, not soiled or dark colored?
- _____ Have you used foil during cooking or to line your oven?
- _____ Are you using standard measuring utensils?

OVEN WILL NOT OPERATE:

- _____ Did you turn the selector and thermostat switches to correct positions?
- _____ Clocks - are knobs in correct positions? See section on clocks and timers.

OVEN LIGHT WILL NOT WORK:

- _____ Is your bulb burned out?
- _____ Is your bulb loose?

NEED SERVICE? WHEN YOUR RANGE REQUIRES SERVICE OR REPLACEMENT PARTS, CONTACT YOUR DEALER OR AUTHORIZED SERVICE AGENCY. CONSULT THE YELLOW PAGES IN YOUR TELEPHONE DIRECTORY UNDER "RANGES" FOR THE SERVICE NEAREST YOU.

BE SURE TO INCLUDE: NAME, ADDRESS, PHONE, MODEL NUMBER, SERIAL NUMBER, AND COMPLAINT. SEE WARRANTY SHEET INCLUDED WITH THIS MANUAL FOR MANUFACTURERS ADDRESS.